SGVL Schneider Globe Valve Linkage For Use with LV and SV Series Actuators







Technical Data		
Fluid	chilled or hot water and steam	
Applicable Valve Size	1/2" [13], 3/4" [19], 1" [25], 1-1/4" [32], 1-1/2" [38], 2" [50]	
Hardware	SS and Nickel plated steel	
Stem Adaptor	steel	
Frame, plate, base	aluminum	
Collar	aluminum (fits VB7 1/2" to 2" /VB9 1/2"-1-1/4" valves) also fits post 1994 1-1/2" to 2" valves	
Coupling	GF Nylon supplied	
Stroke	0.95" [24 mm]	
Mounting Position	360°	
Weight	1.1 lb [0.50 kg]	
Fluid Temp Range (water)	Please Refer to Manufacturer's Valve Specifications	

For close-off pressure reference Select Pro or retrofit technical documentation.

Application


Operation


Default/Configuration

The default set up for a SGVL linkage will be factory installed along with a LV or SV series actuator. Included in the kit will be all the necessary hardware to facilitate mounting to the Schneider valve.

Suitable Actuators


	Non-Spring	Electronic fail-safe
SGVL	LVB(X), SVB(X)	LVKB(X), SVKB(X)








SGVL Schneider Globe Valve Linkage For Use with LV and SV Series Actuators



SVKX24-MFT Technical Data Sheet

Modulating, Electronic Fail-Safe, Linear, 24 V, Multi-Function Technology®





Technical Data	
Power Supply	24 VAC, ±20%, 50/60 Hz, 24 VDC, ±10%
Power consumption in operation	3 W
Power consumption in rest	2 W
position	
Transformer sizing	7 VA (class 2 power source)
Electrical Connection	18 GA plenum cable, 3 ft [1 m], with 1/2"
	conduit connector, degree of protection
Overload Protection	NEMA 2 / IP54
Electrical Protection	electronic throughout full stroke
	actuators are double insulated
Operating Range	210 V (default), 420 mA w/ ZG-R01 (500 Ω , 1/4 W resistor), variable (VDC, PWM, on/
	off, floating point)
Operating range Y variable	Start point 0.530 V
operating range i variable	End point 2.532 V
Input Impedance	100 kΩ for 210 V (0.1 mA), 500 Ω for
	420 mA, 1500 Ω for PWM, On/Off and
	Floating point
Position Feedback	210 V
Stroke	0.75" [19 mm]
Actuating force motor	340 lbf [1500 N]
Direction of motion motor	selectable with switch
Direction of motion fail-safe	reversible with switch
Position indication	Mechanically, with pointer
Manual override	4 mm hex crank (shipped w/actuator)
Running Time (Motor)	default 90 s, variable 35150 s
Running time fail-safe	<35 s
Bridging time	2 s delay before fail-safe activates
Pre-charging time	520 s
Ambient humidity	max. 95% r.H., non-condensing
Ambient temperature	-22122°F [-3050°C]
Storage temperature	-40176°F [-4080°C]
Degree of Protection	IP54, NEMA 2, UL Enclosure Type 2
Housing material	Die cast aluminium and plastic casing
Agency Listing	cULus acc. to UL60730-1A/-2-14, CAN/CSA
	E60730-1:02, CE acc. to 2004/108/EC and
	2006/95/EC
Noise level, motor	45 dB(A)
Noise level, fail-safe	60 dB(A)
Servicing	maintenance-free
Quality Standard	ISO 9001
Weight	3.53 lb [1.6 kg]

[†] Use flexible metal conduit. Push the listed conduit fitting device over the actuator's cable to butt against the enclosure. Screw in conduit connector. Jacket the actuators input wiring with listed flexible conduit. Properly terminate the conduit in a suitable junction box. Rated impulse Voltage 800V. Type of action 1. Control pollution degree 3.

SVKX24-MFT Technical Data Sheet

Modulating, Electronic Fail-Safe, Linear, 24 V, Multi-Function Technology®

Wiring Diagrams

\times

INSTALLATION NOTES



Actuators may be connected in parallel. Power consumption and input impedance must be observed.



Actuators may also be powered by 24 VDC.



A 500 Ω resistor (ZG-R01) converts the 4 to 20 mA control signal to 2 to 10 VDC.



Control signal may be pulsed from either the Hot (Source) or Common (Sink) 24 VAC line.



For triac sink the common connection from the actuator must be connected to the hot connection of the controller. Contact closures A & B also can be triacs. A & B should both be closed for the triac source and open for triac sink.



Actuators with plenum cable do not have numbers; use color codes instead.



Meets cULus requirements without the need of an electrical ground connection.



WARNING! LIVE ELECTRICAL COMPONENTS!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

