Defrost Controller Installation Guide

 ${\bf Controller}\ for\ refrigerated\ cabinets,\ counters\ and\ is lands,\ with\ energy-saving\ strategies$








- Controller for low temperature units
- Power supply for TC3223N5x: 115 VAC
- Power supply for TC3223N7x: 230 VAC
- Cabinet probe and auxiliary probe with a negative temperature coefficient (NTC),
- Door switch or multi-purpose input
- Alarm buzzer
- TTL MODBUS® subordinate port for Building Management System (BMS)
- Cooling or heating operation

MEASUREMENTS AND INSTALLATION

Measurements in mm (inches). Fit the controller to a panel with the snap-in brackets supplied



INSTALLATION PRECAUTIONS


- Ensure that the thickness of the panel is between 0.8 mm and 2.0 mm (1/32 in. and
- Ensure that the working conditions are within the limits stated in the $\emph{TECHNICAL}$ SPECIFICATIONS section.
- Do not install the device close to heat sources, equipment with a strong magnetic field, in places subject to direct sunlight, rain, damp, excessive dust, mechanical vibrations or shocks.
- In compliance with safety regulations, install the device correctly to ensure adequate protection from contact with electrical parts. Fix all protective parts in such a way so as to need the aid of a tool to remove them.

ELECTRICAL CONNECTION



Important

Use cables of an adequate wire gauge for the current running through them. To reduce any electromagnetic interference, connect the power cables as far away as possible from the signal cables



- Power supply for TC3223N5x: 115 VAC Power supply for TC3223N7x: 230 VAC

PRECAUTIONS FOR ELECTRICAL CONNECTION

- If you use an electrical or pneumatic screwdriver, adjust the torque to a maximum of 0.5 N·m (4 in. lb).
- If you move the device from a cold to a warm place, the humidity may cause condensation to form inside. Wait an hour before you switch on the power. Make sure that the supply voltage, electrical frequency, and power are within the set limits. See TECHNICAL SPECIFICATIONS.
- Disconnect the power supply before you do any type of maintenance. Do not use the device as safety device.
- For repairs and further information, contact the Penn sales network.


FIRST-TIME

- Follow the instructions in MEASUREMENTS AND INSTALLATION to install the controller Power up the device as shown in $\it ELECTRICAL\ CONNECTION$ and an internal test runs. The test normally takes a few seconds. When it finishes the display switches off.
- Configure the device as shown in Table 6.1 in SETTINGS.

For recommended configuration parameters for first-time use, see the following			first-time use, see the following table
PAR. DEF. PARAMETER		PARAMETER	MIN MAX.
SP	32 Setpoint		r1 to r2
P2	1	Temperature unit of measurement	0 = °C 1 = °F
d1	0	Defrost type	0 = Electric 1 = Hot gas
			2 = Compressor stopped

- Check that the remaining settings are appropriate; see ${\it CONFIGURATION\ PARAMETERS}.$ Disconnect the device from the mains.
- up the device.
- Power up the device.

4 USER INTERFACE AND MAIN FUNCTIONS



4.1 Switching the device on or off

If POF = 1, tap the ON/STAND-BY key for 4 s.

If the device is switched on, the display shows the P5 value, cabinet temperature by default. If the display shows an alarm code, see ALARMS.

LED	ON	OFF	FLASHING
*	Compressor on	Compressor off	Compressor protection activeSetpoint setting active
*	Defrost or pre-dripping active	-	Defrost delay activeDripping active
@	Evaporator fan on	Evaporator fan off	Evaporator fan stop active
НАССР	Saved Hazard Analysis and Critical Control Point (HACCP) alarm	-	New HACCP alarm saved
(1)	Energy saving active	-	-
2	Request for compressor service	-	Settings activeAccess to additional functions active
°C/°F	View temperature	-	Overcooling or overheating active
Û	Device off	Device on	Device on or off active

If 30 s elapse and you do not press the keys, the display shows the "Loc" label and the keypad locks automatically

Unlocking the keypad

Tap any key for 1 s. The display shows the label "UnL".

4.3 Setting the setpoint

0110011	nat the Repparation	t lookou.
1.	≙SET	Tap the SET key.
2.	√ ₩ •	Tap the UP or DOWN key within 15 s to set the value within the limits r1 and r2.
3.	a set	Tap the SET key or do not operate for 15 s.

Activating manual defrost (if r5 = 0, default)

Check that the keypad is not locked and that overcooling is not active.

Tap the UP key for 2 s.

If P4 = 1 (default), the defrost activates if the evaporator temperature is lower than the d2 threshold.

Silencing the buzzer (if A13 = 1)

Tap any key.

ADDITIONAL FUNCTIONS

Activating or deactivating the overcooling, overheating, and manual energy saving

Check that the keypad is not locked.

FNC 🗸 Tap the DOWN key.

FUNCTION	CONDITION	CONSEQUENCE		
Overcooling	r5 = 0, r8 = 1 and defrost not active	The setpoint becomes "setpoint - r6", for the r7 duration		
Overheating	r5 and r8 = 1	The setpoint becomes "setpoint + r6", for the r7 duration		
Energy saving	r5 = 0 and r8 = 2	The setpoint becomes "setpoint + r4", at maximum for the HE2 duration		

5.2 Navigating the additional functions menu

Before you begin, check that the keypad is not locked. To access the additional functions menu, tap the DOWN key for FNC 🗸 2. To navigate to a label, tap the UP or DOWN key within 15 s. 3. <u> </u>SET To select a label, tap the SET key. FNL If you cannot edit the parameter, the value displays If you can edit the parameter, tap the UP or DOWN key to avigate to the value that you want. **≙** SET To set the parameter value, tap the SET key.

To exit the procedure, tap the ON/STAND-BY key, or do not operate the controller for $60\ s.$

@(1)

Use the additional functions menu to cycle through the labels in the following table

LABEL	VALUE DESCRIPTION		
LS		View HACCP alarm information	
	AL	Low temperature alarm information	
	AH	High temperature alarm information	
	id	Door switch alarm information	
	PF	Power failure alarm information, available when you connect to a TCIF23TSX accessory	
rLS		Delete HACCP alarm information	
149		Command to delete HACCP alarm information	
СН		View compressor functioning hours in hundreds	
rCH		Delete compressor functioning hours	
149		Command to delete compressor functioning hours	
nS1		View compressor start-up number in thousands	
Pb1		Cabinet temperature	
Pb2		Auxiliary temperature	
PrJ		View the project number	
rEU		View the firmware revision	

Alarm information example

Make the electrical connection as shown in ELECTRICAL CONNECTION without powering The following table shows an example of information for a high temperature alarm

LABEL	VALUE	DESCRIPTION
8.0		The critical value was 8.0°F or 8.0°C. The critical value can be cabinet
		temperature or calculated product temperature (CPT).
Sta		The time at which the alarm signaled, for example:
		26 March 2015 at 16:30
		Sta is available when you connect a TCIF23TSX accessory.
	y15	2015
n03		March
	d26	26 March 2015
	h16	16: xx
n30 dur		16:30
		The alarm duration, for example 1 h 15 min
	h01	1 h
	n15	1 h 15 min

6	SETTINGS				
6.1	Setting configurat	ion parameters			
1.	≙SET	Tap the SET key for 4 s. The display shows the label "PA".			
2.	aset	Tap the SET key. The display shows the label "PAS".			
3.	√	Tap the UP or DOWN key within 15 s to set the password.			
4.	aset	Tap the SET key or do not operate for 15 s. The display shows the label "SP".			
5.		Tap the UP or DOWN key to select a parameter.			

	i	
6.	≙SET	Tap the SET key.
7.	₹	Tap the UP or DOWN key within 15 s to set the value.
8.	≟SET	Tap the SET key or do not operate for 15 s.
9.	≙SET	Tap the SET key for 4 s, or do not operate for 60 s, to exit the procedure.

6.2 Setting the date, time, and day of the week

Note: This feature is available if you connect a TCIF23TSX accessory.

	Important
	Important Do not disconnect the device from the mains within 2 minutes of setting the time and
	day of the week.

Check that the keypad is not locked.

-	1.	\	ν I	Tap the DOWN key for 4 s.
	2.	f		Tap the UP or DOWN key within 15 s to select the label "rtc".
	3.	1 29	5 €T	Tap the SET key. The display shows the label "yy" followed by the last two figures of the year.
	4.	f		Tap the UP or DOWN key within 15 s to set the year.
t	5.	Repea	t actions 3. a	nd 4. to set the next labels.
		LAB.	DESCRIPTION	ON
		n	Month (01 t	o 12)
		d	Day (01 to	31)
		h	Time (00 to	23)
		n	Minute (00	to 59)
	6.	1 29	SET	Tap the SET key. The display shows the label for the day of the week.
_	7.	f	<u></u> ^∰ _≠	Tap the UP or DOWN key within 15 s to set the day of the week.
		LAB.	DESCRIPTION	DN
-		Mon	Monday	
		tuE	Tuesday	
		UEd	Wednesday	
		thu	Thursday	
		Fri	Friday	
		Sat	Saturday	
		Sun	Sunday	
	8.	= 9	SET	Tap the SET key. The device exits the procedure.
	9.		D	Tap the ON/STAND-BY key to exit the procedure beforehand.

6.3 Restoring the default factory settings and storing customized settings as

		Important
	Ç,	- Check that the factory settings are appropriate; see CONFIGURATION
		PARAMETERS When you store customized settings, you overwrite the default.

-	1.	25	5€T	Tap the SET key for 4 s. The display shows the label "PA".
-	2.	≙SET		Tap the SET key.
-	3.	₹		Tap the UP or DOWN key within 15 s to set the value.
		VAL.	DESCRIPTION	DN
		149	Restores the	e default factory settings
		161	Stores custo	omized settings as default
	4.	aset		Tap the SET key or do not operate for 15 s. The display sht the label "dEF" when you set the value "149" or the label "M/when you set the value "161".
	5.	SET		Tap the SET key.
-	6.			Tap the UP or DOWN key within 15 s to set "4".
-	7.			Tap the SET key or do not operate for 15 s. The display shows "" flashing for 4 s, then the device exits the procedure.
-	8.			supply to the device.
	9.	1 29	5 €T	Tap the SET key 2 s before step 6. to exit the procedure beforehand.

7 CONFIGURATION PARAMETERS

/	CONFIGURATION PARAMETERS					
∩≡	PAR.	PAR. DEF. SETPOINT		MIN MAX.		
₽≣	SP	32	Setpoint	r1 to r2		
	PAR.	DEF.	ANALOG INPUTS	MIN MAX.		
	CA1	О	Cabinet probe offset	-25°F/°C to 25°F/°C		
	CA2	0	Auxiliary probe offset	-25°F/°C to 25°F/°C		
	PO	1	Probe type	0 = n/a 1 = NTC		
	P1	1	Enable °C decimal point	0 = No 1 = Yes		
	P2	1	Temperature unit of measurement	0 = °C 1 = °F		
Q	P4	1	Auxiliary probe function	0 = Disabled 1 = Evaporator probe (defrost + fan) 2 = Evaporator probe (fan) 3 = Condenser probe		
	P5	0 Value displayed		0 = Cabinet temperature 1 = Setpoint 2 = Auxiliary temperature		
	P8	5	Display refresh time	0 s to 250 s : 10		
	PAR.	DEF.	CONTROL	MIN MAX.		
	r0	4	Setpoint differential	1°F/°C to 15°F/°C		
	r1	-50	Minimum setpoint	-99°F/°C to r2		
	r2	100	Maximum setpoint	r1 to 199°F/°C		
	r4	0	Setpoint offset in energy saving	0°F/°C to 99°F/°C		
*	r5	r5 0 Cooling or heating operation		0 = Cooling 1 = Heating		
	r6	0	Setpoint offset in overcooling/overheating	0°F/°C to 99°F/°C		
	r7	30	Overcooling/overheating duration	0 min to 240 min		
	r8	0	DOWN key additional function	0 = Disabled 1 = Overcooling or overheating 2 = Energy saving		
	r12	0	Position of the r0 differential	0 = Asymmetric around setpoint 1 = Setpoint + r0 differential		
	PAR.	DEF.	COMPRESSOR	MIN MAX.		
	CO	0	Compressor on delay after power-on	0 min to 240 min		
	C2	3	Compressor off minimum time	0 min to 240 min		
÷	C3	0	Compressor on minimum time	0 s to 240 s		
	C3 0 Compressor on minimum time		C	0 4- 240		

Compressor off time during cabinet

Compressor on time during cabinet

0 min to 240 min

0 min to 240 min

C4

C5

10

10

probe alarm

probe alarm

nn T	C3223	Installat	ion Guide Rev. C Part No. 24-7664-03523	3 Page 2 of 2 19 January 2021
	C6	176	Threshold for high condenser temperature warning	0°F/°C to 199°F/°C Differential = 4°F/2°C
	C7	194	Threshold for high condenser temperature alarm	0°F/°C to 199°F/°C
	C8	1	High condenser temperature alarm	0 min to 15 min
	C10	0	delay Compressor hours for service	0 h to 999 h x 100
	PAR.	DEF.	DEFROST (if r5 = 0)	0 = Disabled MIN MAX.
	d0	8	Automatic defrost interval	0 h to 99 h 0 = Only manual
	d1	0	Defrect type	If d8 = 3, maximum interval 0 = Electric
	d1	0	Defrost type	1 = Hot gas
	d2	46	Threshold for defrost end	2 = Compressor stopped -99 to 99 °F/°C
	d3	30	Defrost duration	0 min to 99 min If P3 = 1, maximum duration
	d4 d5	0	Enable defrost at power-on Defrost delay after power-on	0 = no 1 = yes 0 min to 99 min
	d6	2	Value displayed during defrost	0 = Cabinet temperature
				1 = Display locked 2 = dEF label
	d7 d8	0	Dripping time Defrost interval counting mode	0 min to 15 min 0 = Device on hours
			, and the second	1 = Compressor on hours 2 = Hours evaporator
				temperature < d9
				3 = Adaptive 4 = Real time
•	d9	32	Evaporation threshold for automatic defrost interval counting	-99°F/°C to 99°F/°C
	d11 d15	0	Enable defrost timeout alarm Compressor on consecutive time for	0 = No 1 = Yes 0 min to 99 min
			hot gas defrost	
	d16	0	Pre-dripping time for hot gas defrost	0 min to 99 min
	d18	40	Adaptive defrost interval	0 min to 999 min If compressor on and
				evaporator temperature < d22
	d19	6	Threshold for adaptive defrost,	0 = Only manual 0°F/°C to 40°F/°C
			relative to optimal evaporation temperature	Optimal evaporation temperature - d19
	d20	180	Compressor on consecutive time for defrost	0 min to 999 min 0 = disabled
	d21	200	Compressor on consecutive time for	0 min to 500 min If (cabinet temperature -
			defrost after power-on and overcooling	setpoint) > 20°F/10°C
	d22	-4	Evaporation threshold for adaptive	0 = Disabled -10°F/°C to 10°F/°C
			defrost interval counting, relative to optimal evaporation temperature	Optimal evaporation temperature + d22
	PAR.	DEF.	ALARMS	MIN MAX.
	AA	0	Select sensor for high and low	0 = Cabinet temperature
	A1	-20	temperature alarms Threshold for low temperature alarm	1 = Auxiliary temperature -99°F/°C to 99°F/°C
	A2	1	Low temperature alarm type	0 = Disabled
			,	1 = Relative to setpoint 2 = Absolute
	A4	20	Threshold for high temperature	-99°F/°C to 99°F/°C
	A 5	1	alarm High temperature alarm type	0 = Disabled
				1 = Relative to setpoint 2 = Absolute
	A6	12	High temperature alarm delay after power-on	0 min to 99 min x 10
	/10	٠-		
7	A7	15	High and low temperature alarms	0 min to 240 min
			delay High temperature alarm delay after	0 min to 240 min 0 min to 240 min
	A7	15	delay	
	A7 A8 A9	15 15 15	delay High temperature alarm delay after defrost High temperature alarm delay after door closing	0 min to 240 min 0 min to 240 min
	A7 A8 A9 A10	15 15 15	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording	0 min to 240 min 0 min to 240 min 0 min to 240 min
	A7 A8 A9 A10 A11	15 15 15 10 4	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential	0 min to 240 min 0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C
	A7 A8 A9 A10	15 15 15	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms	0 min to 240 min 0 min to 240 min 0 min to 240 min
	A7 A8 A9 A10 A11	15 15 15 10 4	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential	0 min to 240 min 0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED
	A7 A8 A9 A10 A11	15 15 15 10 4	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential	0 min to 240 min 0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration >
	A7 A8 A9 A10 A11 A12	15 15 15 10 4 2	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer	0 min to 240 min 0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12	15 15 15 10 4 2	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal	0 min to 240 min 0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = N0
	A7 A8 A9 A10 A11 A12 A13 PAR.	15 15 10 4 2 0 DEF.	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS	0 min to 240 min 0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR.	15 15 10 4 2 0 DEF.	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal	0 min to 240 min 0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR.	15 15 10 4 2 0 DEF.	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0	15 15 10 4 2 0 DEF. 3	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0	15 15 10 4 2 0 DEF. 3	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation	0 min to 240 min 0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0	15 15 10 4 2 0 DEF. 3	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0	15 15 10 4 2 0 DEF. 3	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan mode during defrost	0 min to 240 min 0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0	15 15 10 4 2 0 DEF. 3	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan mode during defrost and dripping Evaporator fan off maximum time Evaporator fan off time during	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3	15 15 10 4 2 0 DEF. 3 30 0	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan mode during defrost and dripping Evaporator fan off maximum time Evaporator fan off time during energy saving Evaporator fan on time during	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = N0
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4	15 15 10 4 2 0 DEF. 3 30 0 2	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan mode during defrost and dripping Evaporator fan off maximum time Evaporator fan off time during energy saving	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5	15 15 10 4 2 0 DEF. 3 30 0 10	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan mode during defrost and dripping Evaporator fan off time during energy saving Evaporator fan on time during energy saving Evaporator fan on time during energy saving	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer (if duration > A10) 0 = N0
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5	15 15 10 4 2 0 DEF. 3 30 0 10	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Evaporator fan mode during defrost and dripping Evaporator fan off maximum time Evaporator fan off time during energy saving Evaporator fan on time during energy saving Threshold for evaporator fan on after dripping (relative to setpoint) Evaporator fan off delay after	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = N0
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5 F7	15 15 10 4 2 0 DEF. 3 30 0 2 0 10 9	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan mode during defrost and dripping Evaporator fan off time during energy saving Evaporator fan on time during energy saving Threshold for evaporator fan on after dripping (relative to setpoint) Evaporator fan off delay after compressor off Evaporator fan off time with	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5 F7	15 15 10 4 2 0 DEF. 3 30 0 10 9	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Evaporator fan mode during defrost and dripping Evaporator fan off time during energy saving Evaporator fan on time during energy saving Threshold for evaporator fan on after dripping (relative to setpoint) Evaporator fan off delay after compressor off	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5 F7 F9 F15	15 15 10 4 2 0 DEF. 3 30 0 10 9 0 0 0	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Evaporator fan mode during defrost and dripping Evaporator fan off time during energy saving Evaporator fan on time during energy saving Threshold for evaporator fan on after dripping (relative to setpoint) Evaporator fan off delay after compressor off Evaporator fan off time with compressor off	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5 F7 F9 F15	15 15 10 4 2 0 DEF. 3 30 0 10 9 0 0 0	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan off maximum time Evaporator fan off maximum time Evaporator fan off time during energy saving Threshold for evaporator fan on after dripping (relative to setpoint) Evaporator fan off delay after compressor off Evaporator fan off time with compressor off Evaporator fan off time with compressor off Evaporator fan on time with	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5 F7 F9 F15	15 15 10 4 2 0 DEF. 3 30 0 10 9 0 0 0	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan off maximum time Evaporator fan off maximum time Evaporator fan off time during energy saving Threshold for evaporator fan on after dripping (relative to setpoint) Evaporator fan off delay after compressor off Evaporator fan off time with compressor off Evaporator fan off time with compressor off Evaporator fan on time with	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5 F7 F9 F15	15 15 10 4 2 0 DEF. 3 30 0 10 9 0 0 0	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan off maximum time Evaporator fan off maximum time Evaporator fan off time during energy saving Threshold for evaporator fan on after dripping (relative to setpoint) Evaporator fan off delay after compressor off Evaporator fan off time with compressor off Evaporator fan off time with compressor off Evaporator fan on time with	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5 F7 F9 F15	15 15 10 4 2 0 DEF. 3 30 0 10 9 0 0 0	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan off maximum time Evaporator fan off maximum time Evaporator fan off time during energy saving Threshold for evaporator fan on after dripping (relative to setpoint) Evaporator fan off delay after compressor off Evaporator fan off time with compressor off Evaporator fan off time with compressor off Evaporator fan on time with	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5 F7 F9 F15	15 15 10 4 2 0 DEF. 3 30 0 10 9 0 0 0	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan off maximum time Evaporator fan off maximum time Evaporator fan off time during energy saving Threshold for evaporator fan on after dripping (relative to setpoint) Evaporator fan off delay after compressor off Evaporator fan off time with compressor off Evaporator fan off time with compressor off Evaporator fan on time with	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No
	A7 A8 A9 A10 A11 A12 A13 PAR. F0 F1 F2 F3 F4 F5 F7 F9 F15	15 15 10 4 2 0 DEF. 3 30 0 10 9 0 0 0	delay High temperature alarm delay after defrost High temperature alarm delay after door closing Power failure duration for alarm recording High and low temperature alarms reset differential Power failure alarm notification type Enable alarm buzzer FANS Evaporator fan mode during normal operation Threshold for evaporator fan operation Evaporator fan off maximum time Evaporator fan off maximum time Evaporator fan off time during energy saving Threshold for evaporator fan on after dripping (relative to setpoint) Evaporator fan off delay after compressor off Evaporator fan off time with compressor off Evaporator fan off time with compressor off Evaporator fan on time with	0 min to 240 min 0 min to 240 min 1°F/°C to 15°F/°C 0 = HACCP LED 1 = HACCP LED + PF label + buzzer 2 = HACCP LED + PF label + buzzer (if duration > A10) 0 = No

	iO	5	Door switch or multi-purpose input	0 = Disabled
	ĺ		function	1 = Compressor + evaporator
	ĺ			fan off
	ĺ			2 = Evaporator fan off
	ĺ			3 = n/a
	ĺ			4 = Compressor + evaporator fan off
	ĺ			5 = Evaporator fan off
	ĺ			6 = n/a
	ĺ			7 = Energy saving
	ĺ			8 = iA alarm
	ĺ			9 = Device on or off
	ĺ			10= Cth alarm
				11= th alarm
	i1	0	Door switch or multi-purpose input	0 = With contact closed
			activation	1 = With contact open
	i2	30	Open door alarm delay	-1 min to 120 min
	-			-1 = Disabled
	i3	15	Regulation inhibition maximum time	-1 min to 120 min
	<u> </u>		with door open	-1 = Until the closing
	i7	0	Multi-purpose input alarm delay	-1 min to 120 min -1 = Disabled
				If i0 = 10 or 11, compressor
	İ			on delay after alarm reset
	i10	0	Door closed consecutive time for	0 min to 999 min
			energy saving	After regulation temperature <
	ĺ		33 44 3	SP
	ĺ			0 = disabled
	i13	180	Number of door openings for defrost	0 to 240
				0 = Disabled
	i14	32	Door open consecutive time for	0 min to 240 min
			defrost	0 = Disabled
.	PAR.	DEF.	ENERGY SAVING (if r5 = 0)	MIN MAX.
	HE2	0	Energy saving maximum duration	1 min to 999 min
	ļ	l		
_	DAD	חרר	DEAL TIME ENERGY CAVING (if re	0 = Until the door opening
	PAR.	DEF.	REAL TIME ENERGY SAVING (if r5 =	MIN MAX.
			0)	MIN MAX.
_	H01	0	0) Energy saving time	MIN MAX. 0 h to 23 h
Ō			0) Energy saving time Energy saving duration	MIN MAX. 0 h to 23 h 0 h to 24 h
O	H01 H02	0	0) Energy saving time	MIN MAX. 0 h to 23 h
Θ	H01 H02	0	0) Energy saving time Energy saving duration	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday
Ō	H01 H02	0	0) Energy saving time Energy saving duration	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday
Θ	H01 H02	0	0) Energy saving time Energy saving duration	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None
Θ	H01 H02 HEd	0	0) Energy saving time Energy saving duration	MIN MAX. O h to 23 h O h to 24 h O = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday
Φ	H01 H02 HEd	0 0 7	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None
	HO1 HO2 HEd	0 0 7 7 DEF.	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled)
	HO1 HO2 HEd PAR. Hd1 Hd2 Hd3	0 0 7 7 DEF. h-h-h-	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 h-, 1 to 24 h-, 1 to 24
	HO1 HO2 HEd PAR. Hd1 Hd2 Hd3 Hd4	0 0 7 DEF. h- h- h-	O) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 h-, 1 to 24 h-, 1 to 24 h-, 1 to 24
<u> </u>	H01 H02 HEd PAR. Hd1 Hd2 Hd3 Hd4 Hd5	0 0 7 7 DEF. h-h-h-h-h-	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24
Θ	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6	0 0 7 7 DEF. h-h-h-h-h-h-	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR.	0 0 7 7 DEF. h- h- h- h- h- DEF.	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fith daily defrost time Sixth daily defrost time Sixth daily defrost time SAFETIES	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 MIN MAX.
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR. POF	0 0 7 7 DEF. h-h-h-h-DEF. 1	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time Sixth daily defrost time SAFETIES Enable ON/STAND-BY key	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 n-, 1 to 24
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR.	0 0 7 7 DEF. h- h- h- h- h- DEF.	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fith daily defrost time Sixth daily defrost time Sixth daily defrost time SAFETIES	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 1 to 24
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 PAR. POF	0 0 7 7 DEF. h-h-h-h-h-DEF. 1 0	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time SAFETIES Enable ON/STAND-BY key Password	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 1 to 24
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR. POF PAS	0 0 7 7 DEF. h-h-h-h-DEF. 1 0 DEF.	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time SafeTIES Enable ON/STAND-BY key Password REAL TIME CLOCK	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 MIN MAX. 0 = No 1 = Yes -99 to 999 0 = Disabled MIN MAX.
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR. POF PAS	0 0 7 7 DEF. h-h-h-h-h-h-DEF. 1 0 DEF. 0	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time SAFETIES Enable ON/STAND-BY key Password REAL TIME CLOCK Enable clock	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 MIN MAX. 0 = No
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR. POF PAS	O O O 7 T DEF. h-h-h-h-DEF. 1 O DEF. O DEF.	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time SaFETIES Enable ON/STAND-BY key Password REAL TIME CLOCK Enable clock MODBUS	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 MIN MAX. 0 = No 1 = Yes -99 to 999 0 = Disabled MIN MAX. 0 = No 1 = Yes MIN MAX. 0 = No 1 = Yes MIN MAX.
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR. POF PAS PAR. Hr0 PAR.	O O O 7 PEF. PEF. O DEF. O DEF. 247	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time SafeTIES Enable ON/STAND-BY key Password REAL TIME CLOCK Enable clock MODBUS MODBUS address	MIN MAX. 0 h to 23 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 MIN MAX. 0 = No 1 = Yes -99 to 999 0 = Disabled MIN MAX. 0 = No 1 = Yes MIN MAX. 0 = No 1 = Yes MIN MAX. 1 to 247
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR. POF PAS	O O O 7 T DEF. h-h-h-h-DEF. 1 O DEF. O DEF.	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time SaFETIES Enable ON/STAND-BY key Password REAL TIME CLOCK Enable clock MODBUS	MIN MAX. 0 h to 23 h 0 m to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 min MAX. 0 = No 1 = Yes -99 to 999 0 = Disabled MIN MAX. 0 = No 1 = Yes MIN MAX. 1 to 247 0 = 2,400 baud
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR. POF PAS PAR. Hr0 PAR.	O O O 7 PEF. PEF. O DEF. O DEF. 247	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time SafeTIES Enable ON/STAND-BY key Password REAL TIME CLOCK Enable clock MODBUS MODBUS address	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 MIN MAX. 0 = No 1 = Yes -99 to 999 0 = Disabled MIN MAX. 0 = No 1 = Yes MIN MAX. 1 to 247 0 = 2,400 baud 1 = 4,800 baud
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR. POF PAS PAR. Hr0 PAR.	O O O 7 PEF. PEF. O DEF. O DEF. 247	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time SafeTIES Enable ON/STAND-BY key Password REAL TIME CLOCK Enable clock MODBUS MODBUS address	MIN MAX. 0 h to 23 h 0 m to 24 h 0 m Monday 1 m Tuesday 2 m Wednesday 3 m Thursday 4 m Friday 5 m Saturday 6 m Sunday 7 m None MIN MAX. (h m disabled) h m m to 24 h m m m m m m m m m m m m m m m m m m
	PAR. Hd1 Hd2 Hd3 Hd4 Hd5 Hd6 PAR. POF PAS PAR. Hr0 PAR.	O O O 7 PEF. PEF. O DEF. O DEF. 247	0) Energy saving time Energy saving duration Energy saving day REAL TIME DEFROST (if d8 = 4) First daily defrost time Second daily defrost time Third daily defrost time Fourth daily defrost time Fifth daily defrost time Sixth daily defrost time SafeTIES Enable ON/STAND-BY key Password REAL TIME CLOCK Enable clock MODBUS MODBUS address	MIN MAX. 0 h to 23 h 0 h to 24 h 0 = Monday 1 = Tuesday 2 = Wednesday 3 = Thursday 4 = Friday 5 = Saturday 6 = Sunday 7 = None MIN MAX. (h- = disabled) h-, 1 to 24 MIN MAX. 0 = No 1 = Yes -99 to 999 0 = Disabled MIN MAX. 0 = No 1 = Yes MIN MAX. 1 to 247 0 = 2,400 baud 1 = 4,800 baud

8	ALARMS					
COD.	DESCRIPTION	RESET	REMEDIES			
Pr1	Cabinet probe alarm	Automatic	- Check PO			
Pr2	Auxiliary probe alarm	Automatic	- Check probe integrity			
			- Check electrical connection			
rtc	Clock alarm	Manual	Set date, time, and day of the week			
AL	Low temperature alarm	Automatic	Check AA, A1, and A2			
АН	High temperature alarm	Automatic	Check AA, A4, and A5			
id	Open door alarm	Automatic	Check i0 and i1			
PF	Power failure alarm	Manual	- Tap any key			
			- Check electrical connection			
сон	High condenser temperature	Automatic	Check C6			
СОП	warning					
CSd	High condenser temperature	Manual	- Switch the device off and on			
CSu	alarm		- Check C7			
iA	Multi-purpose input alarm	Automatic	Check i0 and i1			
Cth	Compressor thermal switch	Automatic	Check i0 and i1			
	alarm					
th	Global thermal switch alarm	Manual	- Switch the device off and on			
			- Check i0 and i1			
dFd	Defrost timeout alarm	Manual	- Tap any key			
			- Check d2, d3 and d11			

9 ELECT	RICAL RATINGS			
	Units	cULus (UL 60730)		CE (EN 60730)
Output	Applied voltage at 60 Hz	120 VAC	240 VAC	240 VAC
	Resistive amperes	12	12	12
K1	Inductive amperes	_	_	2
compressor relay	Full load amperes	10	10	_
	Locked rotor amperes	60	60	_
K2	Resistive amperes	8	8	5
	Inductive amperes	_	_	2
K2 relay	Full load amperes	4.4	2.9	_
	Locked rotor amperes	26.4	17.4	_
	Resistive amperes	5	5	5
K3	Inductive amperes	_	_	1
evaporator fan relay	Full load amperes	1.5	1.5	_
	Locked rotor amperes	9	9	_

Purpose of the control device	Function controller
Construction of the control device	Built-in electronic device
Container	Black, self-extinguishing
Category of heat and fire resistance	D
Measurements	2 15/16 in. x 1 5/16 in. x 2 5/16 in. (75 mm
	33 mm x 59 mm)
Mounting methods for the control device	Fit the controller to a panel with the snap-in
	brackets supplied
Degree of protection provided by the	IP65 in front
covering	
Connection method	
Fixed screw terminal blocks for wires up to	Micro-MaTch® connector
2.5 mm²	

Maximum permitted length for connection cables					
Power supply:	32.8 ft (10 m)		Analog inputs: 32.8 ft (10 m)		
Digital inputs:	32.8 ft (10 m)		Digital outputs: 32.8 ft (10 m)		
Operating temp	perature		From 32°F to 131°F (from 0°C to 55°C)		
Storage temper	rature		From -13°F to 1	From -13°F to 158°F (from -25°C to 70°C)	
Operating hum	idity		Relative humidity without condensate from		
			10% to 90%		
Pollution status	of the control	device	2		
Compliance					
United States	15, Subpart B	Class A limits		FCC Compliant to CFR47, Part	
Canada			187 CCN SDFY8; 1 003, Class A limits	Industry Canada (IC)	
Europe	the essential r	equirements an		product is in compliance with provisions of the EMC ective	
Power supply	TC3223N5x	115 VAC (+	10% -15%), 50/6	60 Hz (+/- 3Hz), max. 2 VA	
rower supply	TC3223N7x	230 VAC (+	230 VAC (+10% -15%), 50/60 Hz (+/- 3Hz), max.		
Grounding met	hods for the co	ntrol device	None		
Rated impulse-	withstand volta	ge	4 KV		
Over-voltage ca	ategory		III		
Software class	and structure		A		
Analog inputs			2 for NTC probe probe)	2 for NTC probes (cabinet probe and auxiliary probe)	
NTC probes	Sensor type	ß3435 (10 KΩ at 77°F, 25°C)		t 77°F, 25°C)	
·	Measurement	field	-40°F to 221°F (-40°C to 105°C)		
	Resolution		1°F (0.1°C)		
Digital inputs			1 dry contact (door switch/multi-purpose)		
Dry contact		Contact type		5 VDC, 1.5 mA	
		Power supply		None	
		Protection		None	
Digital outputs 3 electro			chanical relays (compressor, defrost and		
		evaporator far	1)		
Type 1 or Type	2 actions		Type 1		
Additional featu	res of Type 1 o	r Type 2	С		
actions					
Displays			3 digits custom display with function icons		
Alarm buzzer			Incorporated		
Communication	ports		1 TTL MODBUS subordinate port for BMS		

11 PRODUCT WARRANTY

This product is covered by a limited warranty, details of which can be found at www.johnsoncontrols.com/buildingswarranty

12 SOFTWARE TERMS

Use of the software that is in (or constitutes) this product, or access to the cloud, or hosted services applicable to this product, if any, is subject to applicable end-user license, open-source software information, and other terms set forth at

www.johnsoncontrols.com/techterms. Your use of this product constitutes an agreement to such terms.

13 SINGLE POINT OF CONTACT					
APAC	Europe	NA/SA			
JOHNSON CONTROLS C/O CONTROLS PRODUCT MANAGEMENT NO. 32 CHANGJIJANG RD NEW DISTRICT WUXI JIANGSU PROVINCE 214028 CHINA	JOHNSON CONTROLS WESTENDHOF 3 45143 ESSEN GERMANY	JOHNSON CONTROLS 507 E MICHIGAN ST MILWAUKEE WI 53202 USA			

14 CONTACT INFORMATION

Contact your local branch office: www.johnsoncontrols.com/locations Contact Johnson Controls: www.johnsoncontrols.com/contact-us



Important

The device must be disposed of according to local regulations governing the collection of electrical and electronic waste.

This document and the solutions contained therein are the intellectual property of Penn and thus protected by the Italian Intellectual Property Rights Code (CPI). Penn imposes an absolute ban on the full or partial reproduction and disclosure of the content other than with the express approval of Penn. The customer (manufacturer, installer or end-user) assumes all responsibility for the configuration of the device. Penn accepts no liability for any possible errors in this document and reserves the right to make any changes, at any time without prejudice to the essential functional and safety features of the



Johnson Controls 507 E. Michigan St. Milwaukee, WI 53202-5211

USA www.penncontrols.com